nexi

Nexi SmartPOS[®] with printer

PAX A910

Operating Instructions



Operating Instructions: Nexi SmartPOS® with printer PAX A910



- 1. Launch Application
- 2. Menu
- 3. Purchase (including Tip, Installments and DCC options)
- 4. MOTO Purchase (Mail Telephone Order)
- 5. <u>Transaction Cancellation (Void)</u>
- 6. Refund
- 7. Pre-Authorization
- 8. <u>Pre-Authorization Completion</u>
- 9. Preview Open Batch
- 10. Close Batch
- 11. Preview Latest Closed Batch
- 12. <u>Transaction Re-print</u>
- 13. Short Transaction Guide to be printed



1. Launch application









Press "Pay"





To start please press "Get started".

Initiate a Purchase
Transaction




You will be automatically redirected to the purchase screen.



2. Menu



On the top left of every screen, click on the 3 dashes to view the Menu.





3. Purchase

[1/2]



If the

customer

wishes to

pay with a digital wallet

(Apple Pay,

Google Pay,

Samsung

Pay), ask

them to

bring their

device


closer to the

POS.


!

* Installments and Tip Options are available to specific merchants upon request and are subject to approval.

1 Enter Amount



Please enter the transaction amount and then click "Charge".



If it is available for your company and if the customer requests it, please press the tip amount or percentage. Alternatively, press the option "No Tip". 3 Installments*



If it is available for your company and if the customer requests it, please enter the number of installments . Alternatively enter the number "0".

4 Card Reading



Tap the card over the POS or insert it into the card reader.

continue 5



3. Purchase


[2/2]



?


** Dynamic Currency Conversion (DCC) is available to specific merchants upon request and is subject to approval.

5 Currency Selection **




If supported for your company and if the customer's card is in a currency other than €, please hand the POS to the cardholder so that they can select the currency of the transaction and press "Continue".





If requested, hand the POS to the customer to enter their PIN. Then press the green key.

7 Processing Payment



The payment transaction is approved.

8 Completion & Receipt



- Receipt to the customer's email address
- Preview on POS
- Print. You can select the printing of customer or merchant receipt or both.



4. MOTO Purchase (Mail – Telephone Order)






MOTO is available upon request and is subject to approval.




Menu Selection




Please select "Other Transactions".





Press "Mail-Telephone Order".






Please enter the transaction amount and then click "Charge".

4 Enter Card Details




Enter the card number, expiration date and 3digit security code and press "Enter Card".

Processing Payment



The payment transaction is approved.

6 Completion & Receipt



- Receipt to the customer's email address
- Preview on POS
- Print



5. Transaction Cancellation (Void)



Only for transactions in the current batch.



Menu Selection

Select **Transaction**



 \leftarrow

Purchase

Card Payment

Visa ***9002

Receipt No.

Confirmation

November 3, 2021 12:55 PM

Transaction status

Transaction **Details**

Transaction Details

Cancel Transaction

Receive in mail

×

€60,00

€60,00

unsettled

1293875541







×


PIN














 Search the transaction you want to cancel.

Press the symbol ">" to view its details and cancel it.

Press "Cancel Transaction".

Tap the card over the POS or insert it into the card reader.

If the customer wishes to pay with a digital wallet, ask them to bring their device closer to the POS.

If requested, hand the POS to the customer to enter their PIN. Then press the green key.

Please press:

- · Receipt to the customer's email address
- Preview on POS
- Print



Please select

"Transactions List".

6. Refund














5 PIN























Please select "Other Transactions".

Press "Refund".

Enter the amount to be refunded and then click "Charge".

If installments and/or DCC are supported, the relevant screens will appear. Tap the card over the POS or insert it into the card reader.

If the customer wishes to pay with a digital wallet, ask them to bring their device closer to the POS. If requested, hand the POS to the customer to enter their PIN. Then press the green key.

The refund is approved.

- Receipt to the customer's email address
- Preview on POS
- Print




7. Pre-Authorization







This transaction is available to specific merchant categories (hotels, travel agencies, car rentals etc).

















5 PIN



Processing Completion & Receipt



Please select "Other Transactions".

Settings

Support

Press
"Pre-Auth
Transactions".
On the next
screen press
"Pre-Auth".

Enter the Pre-Auth amount and then click "Charge".

Tap the card over the POS or insert it into the card reader.

If the customer wishes to use a digital wallet, ask them to bring their device closer to the POS.

If requested, hand the POS to the customer to enter their PIN. Then press the green key.

The transaction is approved.

Please press:

- Receipt to the customer's email address
- Preview on POS
- Print



10

8. Pre-Authorization Completion





Merchant ID: 0800049678

Merchant Type: Car Rental

Transactions List

Other Transactions

Batch

Settings

Support

Terminal ID: 80012247

Serial No: 1492629751

Purchase

nexi



Refund

Other Transactions

Pre Auth

Telephone

Order



= €60,00

€34,20

Card No:400****013

€85,90 Card No:400****D98

€20,00 Card No:400****456

€12,50 Card No:400****123

€45,00 Card No:400****987

€23,80 Card No:400****588

€15,00 Card No:400****543


Yesterday, Nov 2

Pre Auth Selection
















Please select "Other Transactions".



- Select the transaction you want from the list
- Click on > to view the "Transaction Details" and proceed with the completion.

Tap the card over the POS or insert it into the card reader.

If the customer wishes to use a digital wallet, ask them to bring their device closer to the POS.

the POS to the customer to enter their PIN. Then press the green key.


- Receipt to the customer's email address
- Preview on POS
- Print



9. Preview Open Batch







Please select "Batch".






Press "Preview Open Batch".





The open batch appears on screen. You may press "Print" to print it.





Select "Summary" or "Detailed" Receipt and press "OK".




10. Close Batch



<u>?</u>\


It is recommended to run daily, if transactions are made.

1 Menu Selection




Select "Batch".

Select
"Close Batch"




Press "Close Batch".

Select
Type of Receipt



Select "Summary" or "Detailed" Receipt and press "OK".

Successful Batch Close




Press "OK".
The batch is closed.



11. Preview Latest Closed Batch








Please select "Batch".






Press "Preview Latest Closed Batch".

Preview Latest Closed Batch



The latest closed batch appears on screen. You may press "Print" in order to print it.






Select "Summary" or "Detailed" Receipt and press "OK".



12. Transaction Re-Print









Please select "Transactions List".

2 Select Transaction




Select the transaction you want to re-print.





Press "Print".





Select the type of receipt you want to be printed (merchant, customer, both).



Short Transaction Guide - Nexi SmartPOS® with printer PAX A910

TRANSACTION TYPE TRANSACTION FLOW **ENTER THE 2** CARD READING **COMPLETION & RECEIPT (VIA EMAIL, VIEW ON** 1 SELECT "PAY" **PURCHASE** AMOUNT AND (CONTACTLESS / CHIP & (IF REQUESTED) SCREEN, PRINT) FROM THE MENU PRESS "CHARGE" PIN/ MAGNETIC) **PURCHASE WITH** 3 ENTER NUMBER OF CARD READING 2 ENTERTHE **5** ENTER PIN 1 SELECT "PAY" 6 COMPLETION & RECEIPT (VIA **INSTALLMENTS** INSTALLMENTS OR "0" (CONTACTLESS / CHIP AMOUNT AND FROM THE MENU EMAIL, VIEW ON SCREEN, PRINT) (IF REQUESTED) **UPON AVAILABILITY** & PIN/ MAGNETIC) PRESS "CHARGE" 3 ENTER TIP AMOUNT (FROM ₄ CARD READING 1 SELECT "PAY" **ENTER PIN** 6 COMPLETION & RECEIPT (VIA 2 ENTER THE **O PURCHASE WITH** SELECTION) OR "NO TIP" (CONTACTLESS / CHIP EMAIL, VIEW ON SCREEN, PRINT) FROM THE MENU" AMOUNT AND (IF REQUESTED)

OPTION

3 PRESS

"CANCEL

TRANSACTION"



VOID

UPON AVAILABILITY

REFUND

ONLY FOR TRANSACTIONS


IN THE CURRENT BATCH







CLOSE BATCH





1 SELECT



"TRANSACTION LIST"

FROM THE MENU

1 SELECT "BATCH"

FROM THE

MENU







"REFUND"

PRESS "CHARGE"

AND CANCEL IT.

PRESS






> SELECT THE TRANSACTION YOU WANT

TO CANCEL . PRESS THE SYMBOL" >"


TO VIEW THE TRANSACTION DETAILS



3 ENTER REFUND AMOUNT

IF SUPPORTED INSTALLMENTS AND/OR DCC

THE RELEVANT MENU WILL FOLLOW.



(CONTACTLESS / CHIP

(CONTACTLESS / CHIP &

4 CLOSE BATCH IS COMPLETED AND

RECEIPT IS PRINTED (SUMMARY OR

DETAILED AS SELECTED IN STEP 3).

& PIN/ MAGNETIC)

4 CARD READING

PIN/ MAGNETIC)

4 CARD READING











6 COMPLETION & RECEIPT (VIA

EMAIL, VIEW ON SCREEN, PRINT)

EMAIL, VIEW ON SCREEN, PRINT)

Short Transaction Guide - Nexi SmartPOS® with printer PAX A910



TRANSACTION FLOW



1 SELECT "OTHER TRANSACTIONS" FROM THE MENU PRESS "MAIL – **TELEPHONE** ORDER"

AMOUNT

A ENTER THE CARD DETAILS (NUMBER, EXPIRATION DATE, CVC/CVV)

EMAIL, VIEW ON SCREEN, PRINT)

COMPLETION & RECEIPT (VIA



DCC PURCHASE (Currency Conversion) **UPON AVAILABILITY**

UPON AVAILABILITY

FROM THE MENU

1 SELECT "PAY" **2** ENTER **AMOUNT**

3 CARD READING

A HAND THE POS TO THE CUSTOMER TO SELECT CURRENCY, CURRENCY (CONTACTLESS /

6 COMPLETION & RECEIPT (VIA





PRE-AUTHORIZATION

COMPLETION

FOR PRE-AUTHORIZED

PREVIEW LATEST

CHIP & PIN/ MAGNETIC)


DISPLAYED 4 ENTER AMOUNT

5 ENTER PIN (IF REQUESTED) **CONVERSION AMOUNT AND FEE ARE**

EMAIL, VIEW ON SCREEN, PRINT)

COMPLETION & RECEIPT (VIA





TRANSACTIONS" FROM THE MENU

SELECT "OTHER

"PRE-AUTH TRANSACTIONS"

2 PRESS

PRESS

PRESS

"PRE-AUTH

TRANSACTIONS"

3 PRESS "PRE-AUTH" **3** PRESS

"PRE-AUTH

SCREEN

POS SCREEN

AND PRESS "CHARGE" 4 SELECT THE

PRE-AUTHORIZED

(CONTACTLESS / CHIP & PIN/ MAGNETIC) 5 CARD READING (CONTACTLESS /

5 CARD READING

EMAIL, VIEW ON SCREEN, PRINT) (IF REQUESTED) **6** ENTER PIN (IF REQUESTED)

6 ENTER PIN

7 COMPLETION & RECEIPT (VIA EMAIL, VIEW ON SCREEN, PRINT)







1 SELECT "BATCH"

MENU



"PREVIEW OPEN BATCH"

COMPLETION" TRANSACTION TO PREVIEW THE OPEN **BATCH ON THE POS**

4 OPTIONALLY.

CHIP & PIN/ MAGNETIC) 5 PRESS "SUMMARY"

6 PRINT THE CURRENT OPEN **BATCH**



FROM THE MENU. **CLOSED BATCH**

- "PREVIEW LATEST CLOSED BATCH"
- 3 PREVIEW THE LATEST 4 OPTIONALLY, **CLOSED BATCH ON THE** PRESS "PRINT"

PRESS "PRINT"

OR "DETAILED" RECEIPT AND PRESS "OK". 5 PRESS "SUMMARY" OR

PRESS "OK".

6 PRINT THE LATEST CLOSED **BATCH** "DETAILED" RECEIPT AND



